



Assembly Instructions

Ultimate Folding Screen Portable Projection Screen by Draper



***Please Note:**
For easier surface attachment, start in one corner, then work your way around the frame.

****Caution: Beware of pinch points.**



Caution: Make sure all hinges and joints are locked before raising screen to standing position.

DRAPER®

411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999
www.draperinc.com ■ fax 765-987-7142

Copyright © 2008 Draper Inc. Form UltimateFoldingScreen_Inst08 Printed in U.S.A.

If you encounter any difficulty installing or servicing your Ultimate Folding Screen by Draper, call your dealer or Draper, Inc., Spiceland, Indiana, (765) 987-7999 or fax (765) 987-7142.